

# **OXYGEN DEFICIENCY**



#### **EUROPEAN INDUSTRIAL GASES ASSOCIATION**

AVENUE DES ARTS 3 - 5 • B-1210 BRUSSELS

PHONE +32 2 217 70 98 • FAX + 32 2 219 85 14 • E-mail : info@eiga.org

© EIGA 2002 - EIGA grants permission to reproduce this publication provided the Association is acknowledged as the source

#### **DISCLAIMER**

All technical publications of **EIGA** or under EIGA's name, including Codes of practice, Safety procedures and any other technical information contained in such publications were obtained from sources believed to be reliable and are based on technical information and experience currently available from members of EIGA and others at the date of their issuance.

While EIGA recommends reference to or use of its publications by its members, such reference to or use of EIGA's publications by its members or third parties are purely voluntary and not binding. Therefore, EIGA or its members make no guarantee of the results and assume no liability or responsibility in connection with the reference to or use of information or suggestions contained in EIGA's publications.

EIGA has no control whatsoever as regards, performance or non performance, misinterpretation, proper or improper use of any information or suggestions contained in EIGA's publications by any person or entity (including EIGA members) and EIGA expressly disclaims any liability in connection thereto.

EIGA's publications are subject to periodic review and users are cautioned to obtain the latest edition.



### A SERIOUS HAZARD

It's a phenomenon



**SUDDEN** 



**3 WEEKS WITHOUT FOOD** 

**3 DAYS WITHOUT DRINK** 

**3 MINUTES WITHOUT BREATHING** 


**2 BREATHS WITHOUT OXYGEN** 


**ENDANGER YOUR LIFE** 

### IN CASE OF TOTAL OXYGEN DEFICIENCY the blood suddenly loses its oxygen

#### NORMAL CONDITION

#### **SUDDEN 02 DEFICIENCY**





WITH 0% OXYGEN, THE SECOND BREATH WILL CAUSE LOSS OF CONSCIOUSNESS WITHOUT WARNING

WITHIN A FEW MINUTES,
BRAIN DAMAGE MAY BE IRREVERSIBLE

### IN CASE OF PROGRESSIVE OXYGEN DEFICIENCY Oxygen content is decreasing in blood

O<sub>2</sub> content less than 18%

- **4** Vertigo
- **headache**
- \*\*speech difficulties

Progressive asphyxiation

- neduction and loss of
- consciousness
- dulling of the mind
- 1 loss of muscle control

These symptoms are similar to those of general malaise and are not recognised as asphyxiation by the victim (inert gases are odourless, colourless, tasteless)

The victim tries to overcome this by himself
THE VICTIM DOES NOT CALL FOR HELP

**OVER A CERTAIN THRESHOLD, THE VICTIM CAN'T REACT:** 

THE LOSS OF CONSCIOUSNESS IS SUDDEN

BUT

## In all cases: THE VICTIM NEVER REALISES THE RISK

With less than 6% of oxygen:

immediate loss of consciousness

If the Oxygen atmosphere deficiency is only between 10 and 18%:

THE VICTIM FEELS ONLY GENERAL MALAISE

AND DOES NOT RELATE THIS

TO THE ONSET OF ASPRYXATION

#### **OXYGEN IS ESSENTIAL FOR:**

# HUMAN LIFE and BRAIN PROCESSES

#### If the blood fails in bringing oxygen:

- Cells don't operate anymore
  - Loss of consciousness
  - ♦ Irreversible consequences (paralysis, comatose state, ...)

.... DEATH






### BUT .... REMEMBER:

Asphyxiation is a phenomenon ...

- INSIDIOUS
- 創
- SUDDEN
- WITHOUT WARNING





# How can you identify a confined space?

A confined space is a space which has any of the following characteristics :

Ilimited opening for entry and exit

unfavourable natural ventilation

not designed for continuous worker occupancy

29/10/02 EIGA Page 11



# How can you identify a confined space?

If you are required to construct or work in a:



Boiler, cupola, degreaser, furnace, pipeline, pit, pumping station, reaction or process vessel, septic tank, sewage digester, sewer, silo, storage tank, ship's hold, utility vault, vat, or similar type of enclosure ...



You are working in a confined space



## Attention!

O<sub>2</sub> deficient atmospheres can arise also in normal working areas, when gases are stored or used

**EIGA** 



# You must:

▲ Be aware of the risk,
▲ Always implement a safe system of work before allowing people to enter into a confined space



# You must:



- Make operators aware of the risk
- Implement a procedure to authorise the access
- Warn people of the danger, place signs at entrances to areas where O<sub>2</sub> deficiency may arise
- A Develop and apply safety measures



### You must also:



▲ Develop and apply appropriate safety measures

#### **AND**

Always monitor the oxygen content



#### **IN ALL CASES:**

PLACE SIGNS
TO WARN OF
THE DANGER

#### TO ALERT THE OPERATORS

△Inform about the risk

▲ Train in the method to detect the danger



### RESCUE

Rescuers must be trained in and follow established emergency procedures and use appropriate equipment and techniques Rescue should be well planned and

drills should be conducted frequently on emergency procedures

Remember : an unplanned rescue will probably be your last

#### **KEY WORD:**



- When you design a gas installation
- When you install and commission a gas installation
- When you work on a gas installation
- **▶** Before acting in an emergency or abnormal event
- Before reacting to any accident or incident

# MISTAKES IN GAS USE: Preventive measures

- RESPECT PRODUCT SPECIFIC

  CONNECTIONS designed to segregate product
- > IDENTIFY PIPES
- INFORM users: Safety data sheets, safety notices
- NEVER IMPROVISE REPAIRS on installations

# MISTAKES IN GAS USE: Preventive measures

- > ALWAYS CHECK WHERE GAS RELEASES WILL GO:
  - the cold vapour from cryogenic liquids
  - vent exhausts
  - the outlets of safety valves and rupture discs
- **VERIFY** periodically the extraction efficiency
- Install, if necessary, an ANALYSER with alarm
- VENT rooms where liquid gases are utilised or stored

#### SPACES WHERE INERTING IS CARRIED OUT:

- to protect a product, or
- to allow work, such as welding
- > EXPLAIN ASPHYXIATION DANGER
- CREATE A PROCEDURE TO ENTER: WORK PERMIT
- PREPARE FOR EMERGENCIES with appropriate equipment:
  - self contained breathing apparatus
  - oxygen meter
  - safety harness
  - ropes
  - winch

TRAIN PEOPLE to verify the equipment & procedures before issuing the permit



#### MEASURES FOR ENTERING A CONFINED SPACE

Before entering: assess risks and consequences to yourself and other

#### BEFORE AN ACCIDENT, THINK ABOUT:

- ☑ Pipe vents to a safe area
- ☑ Do not rely on a closed valve which may leak
- ✓ Always use physical isolation methods, e.g. blind flanges

## ABNORMAL CIRCUMSTANCES, CONSIDER:

- Any noise indicating a possible leak
- ☑ Abnormal fluid flow

DON'T RUSH ... THINK!



### CONCLUSION

- If you hear a gas leak,
- If you see cold vapours,
- If you have symptoms of general malaise,
- If a colleague lies unconscious

CONSIDER the ASPHYXIATION RISK LEAVE the DANGER AREA IMPLEMENT the APPROPRIATE PROCEDURE